

FRANKLIN[®] SENSORS

MAGNETIC 

12" iLEVEL

Model: i12

OPERATING INSTRUCTIONS


POWER ON/OFF

- Press down once on the power button. LEDs should illuminate immediately.
- Press down again while illuminated to turn power off.
- The unit will timeout (power off) if left untouched for 5 minutes.

HOW TO READ THE I-LEVEL

The iLevel is designed to level both vertical and horizontal surfaces by displaying a range of colors diagramed:

- Green: Level.
- Yellow: Approaching level.
- Red: Not level.



Turns Green When Level

REPLACING THE BATTERIES

- Remove the battery cover by sliding the cover and lifting.
- Remove the battery and dispose of it properly. Please recycle.
- Replace with 1 new AA battery.
- Install battery according to polarity (+/-).
- Close battery cover by sliding the cover into place.

***MAGNETIC:** Securely attaches to metallic surfaces.

This device may not cause harmful interference. This device must accept any interference received, including interference that may cause undesired operation.



Requires 1
AA battery.
Battery included.

FRANKLIN SENSORS INC.

6675 N Pollard Lane
Meridian, ID 83646
208-918-2403

www.franklinsensors.com

©2024 Franklin Sensors Inc.

Patent No. 11,852,503

INSi12.0



Activate Your Limited Lifetime Warranty

1. Scan the QR Code
2. Enter Info
3. Warranty Activated

Did Something Go Wrong?

Please call us!

208-918-2403

