# **FRANK** NSOR

MAGNETIC

2" iLEVEL

Model: iA12

### **OPERATING** INSTRUCTIONS

### **POWER ON/OFF**

- Press down once on the power button. LEDs should illuminate immediately.
- Press down again while illuminated to turn power off.
- The unit will timeout (power off) if left untouched for 5 minutes.

## **HOW TO READ THE I-LEVEL**

The iLevel is designed to level both vertical and horizontal surfaces by displaying a range of colors diagramed:

- Green: Level. Yellow: Approaching level.
- Red: Not level.



### Turns Green When Level

### REPLACING THE BATTERIES Remove the battery cover by

- sliding the cover and lifting. Remove the battery and dispose of
  - it properly. Please recycle. Replace with 1 new AA battery.
  - Install battery according to
- polarity (+/-). Close battery cover by sliding the cover into place.

### \*MAGNETIC: Securely attaches to metallic surfaces

This device may not cause harm-ful interference. This device must accept any interference received, including interference that may cause undesired operation.



Requires 1 A battery. Battery included.

### FRANKLIN SENSORS INC.

6675 N Pollard Lane Meridian, ID 83646 208-918-2403

www.franklinsensors.com ranklin Sensors Inc. 2024 F

Patent No. 11,852,503

INSiA12.0



#### **Activate Your Limited** Lifetime Warranty

- 1. Scan the QR Code
- 2. Enter Info
- 3. Warranty Activated

Did Something Go Wrong? Please call us! 208-918-2403

